



NOTES:

- REQUIRES QTY 2 OF OPTICAL FERRULES PART NUMBER 8A-2204-2-MACH (SANITARY) OR 8A-2204-1-MACH (STD.)
- WELD AS SHOWN.
- ALIGNMENT CAN BE MAINTAINED USING ALIGNMENT PIPE BAR (FOR SANITARY APPROXIMATELY 1-7/8 INCH DIA) FOR SLIDING FIT IN PART 8A-2204-() -MACH.
- FERRULES FLANGE FACES TO BE PARALLEL WITHIN 1/16 INCH FOR PIPES UP TO 10 INCH DIA (1/32 INCH FOR PIPES 3 INCH DIA. AND UNDER).
- WARNING: OBSERVE GOOD SAFETY PROCEDURES WHEN WELDING. PRESSURE TEST AFTER COMPLETE INSTALLATION.
- RECOMMENDED INSTALLATIONS:
 - DATUM-A-HORIZONTAL $\pm 20^\circ$
 - RESERVED
 - KEEP OPTICAL CELL WINDOWS SUBMERGED (FULL PIPE)
 - AVOID BUBBLES-INCREASE BACK PRESSURE WHERE REQUIRED.
 - FOR MAINTENANCE ACCESS, LOCATE 4 TO 5 FEET ABOVE FLOOR OR PLATFORM SEE ALSO TECHNICAL MANUAL.
- STANDARD LENGTH SHOWN-OTHER MODELS AVAILABLE LP=LIGHT PATH. ELECTRONIC HOUSING NOT SHOWN. SEE TECHNICAL MANUAL FOR COMPLETE INSTALLATION INFORMATION.
- DIMENSIONS ARE IN INCHES.

McNAB, INCORPORATED
 20 N. MacQUESTEN PKWY., MT. VERNON, N.Y., USA 10550
 (914) 699-1616 TELEFAX (914) 699-1671 TELEX 701621

INSTALLATION DRAWING
 OPTICAL FERRULES
 MODEL AP VI E

	MODELS AP VI	REV.
SCALE: NONE	A92-96	SHEET 1 OF 1